

### **Alerts and Faults**



### **Agenda**

- What Are Telematics "Subscriptions"/Notifications?
- How Do I Know If A Tractor Has Active Alerts/Faults?
- How Do I See Details of Alerts/Faults Coming From A Tractor?
- How Do I Set Up "Subscriptions"/Notifications for Alerts/Faults?
- What Do Fault and Alerts Messages Look Like?




# What Are Telematics "Subscriptions"/Notifications?


- The main types of Notifications you can set up in the Portal are:
  - DM1 Faults
  - Alerts (Telematics-generated messages)
- DM1 Faults
  - These alerts allow you to know when the tractor's electrical system notices an issue
  - These are the same messages you would see in the tractor cab
- Alerts
  - The Telematics system has a set of notices that are pre-programmed to alert you to important things
  - These include things like "Low Fuel", " "Machine Running", etc.



## How Do I Know If A Tractor Has Active Alerts/Faults?

- You can see that an Asset has an active alarm associated with it in a couple of different ways
  - Map View pin will turn orange with an exclamation mark
  - List View will show an exclamation mark overlaid on the Tractor icon
  - When viewing a Tractor Dashboard, you will see the alarm count in a red box beside the Alerts and DM1 Faults Menu Bar tabs








#### **How Do I See Details of Alerts/Faults Coming From A Tractor?**

- You can find details from both a Fleet and Machine view
  - Fleet-wide info is available from the Events Menu in the top Menu Bar
  - Machine-specific info is available from the Tractor Dashboard Menu Bar


DM1 Faults and Alerts are often found together in menus, since the detail tables





#### **How Do I See Details of Alerts/Faults Coming From A Tractor?**


 The tables of information for Alerts and DM1 Faults are slightly different layouts, but function the same way






## How Do I Set Up "Subscriptions"/Notifications for Alerts/Faults?

- Four types of Messages related to Telematics are the most common
  - Alerts (set tractor-by-tractor)
  - DM1 Faults (set tractor-by-tractor)
  - Geofence barrier breaks (set for each Geofence)
  - Maintenance due (set tractor-by-tractor)
- You can choose three options for receiving messages
  - No automated messages (only indicators will be in the Portal
  - Email notifications
  - SMS (Text) notifications









#### What Do Fault and Alerts Messages Look Like?

- DM1 Fault and Alert Message settings can be adjusted for a user Asset by Asset
- The information provided is identical in both formats (Text or Email)





VDM-testing triggered an alert with the

Please login to <a href="https://portal.versatile-cbx.com/#/asset/d2a76c5b-810c">https://portal.versatile-cbx.com/#/asset/d2a76c5b-810c</a>

"Amber Lamp" = 1 (equalTo 1)

-477c-9b29-f1077ae17aa1?tab=

dashboard for additional informati

following conditions:

View all